

# xMount

Holds your iPad!


xMount@Operating instructions

[www.xmount.de](http://www.xmount.de)

# xMount@Car&Home



- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- For fastening your xMount Car & Home at the intended surface please use the enclosed suction connector.
- Moreover, please absolutely ensure the fastening surface is clean and free from grease, this surface is required to be cleaned every 24 hours.
- Using the posterior adjusting screw you can individually adjust the inclination angle of your xMount.
- Using the anterior adjusting screw you can turn the tower base by 360 degrees.
- Before usage, these adjusting screws are required to be tightened.



# xMount@Car for the headrest




- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- Fasten xMount Car at the headrests of the driver or passenger seat.
- For this purpose, loose the four screws of the holder and remove the cover.
- Insert the rod of the headrest into the recess of the holder and fasten it using the cover and the four enclosed screws.
- Ensure for a firm stability of the holder. Bend the gooseneck according to your requests.

## Contact:

Benjamin Hermann Handels UG  
Mühlweg 12 c . 61169 Friedberg  
+49 (0) 6 031 - 67 28 106  
[info@xmount.de](mailto:info@xmount.de)

[www.xmount.de](http://www.xmount.de)

# xMount@Air



- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- Fasten xMount Car for ventilation at the centre of the double lamella of the centre console. Click the clamps into the lamella and ensure everything is properly secured and fixed.
- For the stabilization of the holder please adjust the hinge on the back side of the holder according to your request.
- Using the posterior adjusting screw you can individually adjust the inclination angle of xMount as well as the tower base which is turnable by 360 degrees.
- Before usage, these adjusting screws are required to be tightened.

## xMount@Tube/Bike




- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- Fasten xMount Tube by loosening the two lateral screws of the holder.
- Place the rubber pads depending on the tube thickness around the tube where to fasten the mount. At least one pad is required to be used. This pad protects the mount against slipping.
- Now determine whether to fasten the iPad vertically or horizontally by loosening the screw in the centre of the fastening and defining the position. Tighten this screw again now.
- Now fasten both half shells using the lateral screws. Check for an accurate stability.

### Contact:


Benjamin Hermann Handels UG  
Mühlweg 12 c . 61169 Friedberg  
+49 (0) 6 031 - 67 28 106  
[info@xmount.de](mailto:info@xmount.de)

[www.xmount.de](http://www.xmount.de)

# xMount@Wall



- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- Fasten xMount Wall using the enclosed fastening material.
- Mark the drilling locations using a pencil. Use xMount Wall as a template here.
- In the event of a stone wall drill two holes at the position intended by you using a 6 mm masonry drill.
- Fasten xMount using the two enclosed wall plugs and screws.
- Using the interior adjusting screw you can adjust the inclination angle as well the tower base which is turnable by 360 degrees.



- Remove xMount from the packaging.
- Fasten xMount at the fastening system selected by you with the catch mechanism clicking into place.
- Before using xMount, please check whether the fastening system has clicked into place correctly.
- You must notice a hearable click.
- Fasten the adapter on the right side using the enclosed screws.
- Hook the suction cup into the adapter plate and lock the retaining nut.
- Using the posterior adjusting screw you can individually adjust the inclination angle of your xMount.
- Using the anterior adjusting screw you can turn the tower base by 360 degrees.
- Before usage, these adjusting screws are required to be tightened.

## Contact:

Benjamin Hermann Handels UG  
Mühlweg 12 c . 61169 Friedberg  
+49 (0) 6 031 - 67 28 106  
[info@xmount.de](mailto:info@xmount.de)

[www.xmount.de](http://www.xmount.de)

# xMount@Safety instructions

## **Safety instructions**

of Benjamin Hermann Handels UG for iPad holders.

The following safety instructions shall be absolutely observed.

Please only apply this product in its intended manner.

Any use other than for this purpose may particularly involve damages to the product or its environment. A strong solar irradiation may affect the function of the product. For additional technical data and general information please refer to the product on our homepage [www.xmount.de](http://www.xmount.de)

## **General information**

The product must not be used during driving. When fastening the product in the vehicle please ensure the field of view not being restricted and comply with the StvZO (Road Traffic Licensing Regulations) here.

The product is provided for a temperature range between minus ten to plus sixty degrees Celsius. The suction cup mounts are only suitable for a temporary mounting on a smooth and clean surface. Before utilization please make sure the mounting surface is clean and free from grease. Bike mounts have a speed limitation of 20 km/h. Non-observance may cause the mount or the device to be mounted becoming loose and getting damaged. Subsequent damage caused by devices fallen down cannot be excluded. Moreover, your device may probably get scratched on the back side. Please exclusively use the parts delivered for mounting. Never carry any floor stand at the tube since this may involve damages. All screws shall be tightened with not more than 10 newtons. Kindly keep these safety instructions and further documents together with your device. Should you hand over this product to third parties, please also hand over the overall documentation.

## **Cleaning**

For cleaning, please do not apply any cleaning sprays or solutions of any kind that include alcohol or other inflammable liquids.

## **Repair**

Repair work at the product shall be exclusively carried out by professionals. Unauthorized opening and inappropriate repair work may involve considerable danger for the user (particularly the risk of functional disorders, loose parts, fire hazard).

## **Preventive measures for children**

For the avoidance of injuries, please make sure children, particularly infants, do not get in contact with the following devices and objects. Small parts of the device, accumulators, batteries, screws, cables and packaging material (e.g. plastic bags) may be swallowed.

## **Transport and safekeeping**

Please protect the product particularly against shocks, impurities, strong solar irradiation, humidity and electrostatic charge. Do not drop the device and do not expose it to any intense vibrations.

## **Contact:**

Benjamin Hermann Handels UG  
Mühlweg 12 c . 61169 Friedberg  
+49 (0) 6 031 - 67 28 106  
[info@xmount.de](mailto:info@xmount.de)

[www.xmount.de](http://www.xmount.de)



# xMount@Safety instructions

## External power supply

For power supply of the product, you are allowed to exclusively use the defined accumulator and the supplied adapter. You will find further information about this in the operating instructions of the product. Please only use adapters and accumulators released for your product. When connecting and disconnecting the cables please observe the information in the operating instructions of the product. Adapters used in vehicles may be exclusively operated under the supervision of adults. If the product is switched on, please do not keep it in an environment with a poor air circulation. Otherwise, this may particularly cause damages to the product or even fire. Please do not keep charging devices, adapters, accumulators and batteries near a source of heat. Excessive heat may cause the charging device and adapter catching fire. Please disconnect them from the power supply if not supervised by adults. Please make sure the contacts of your power socket are clean. Adapters may get very hot. Never hide the ventilation slots of the adapter. Do not use damaged cables, otherwise there is the risk of an electric shock or fire.

## Positioning and operation

Mount the product to such an extent that it cannot cause any injury neither in the range of an airbag nor in the event of an accident, particularly not in the impact area of the head or body. Usually, the products are designed for being mounted at the screen, at the air grid or at the headrests. For products with electrical supply please pay attention to the following: Lay the cables in a manner that they do not cause any danger (risk of stumbling) and are not damaged. When connecting the cables please pay attention to the corresponding information in the operating instructions of the product. The assembly of the product and also the assembly of accessory parts must by no means impede the driver during driving the vehicle. Do not operate, mount or adjust this or other products during driving. During driving, please do not reach for or look for objects that have fallen down.

## Anti-theft system

The xMount anti-theft system is construed for simple theft (removal). It cannot withstand theft attempts by tools and brute force. For the anti-theft protection, please exclusively use locks of the brand Burgwächter C-Line 220-20 with a diameter of 11 mm in order to avoid the mount sliding on. Moreover, the device comes with an additional cover that is required to be used.

## Attention

No liability is assumed for damages resulting from misuse of the product or non-observance of the safety instructions.

## Contact:

Benjamin Hermann Handels UG  
Mühlweg 12 c . 61169 Friedberg  
+49 (0) 6 031 - 67 28 106  
[info@xmount.de](mailto:info@xmount.de)

[www.xmount.de](http://www.xmount.de)